

Palletizing Televisions



PACKAGING GUIDE

1



Begin by placing a pallet in an open work area.

2



place the most flat, box-like televisions on the first layer. Typically, four televisions will fit on the first layer.

3



Secure the first layer with stretch wrap. 80-gauge stretchwrap works well for wrapping electronics.

4



Stack a second layer of televisions on top of the first. Don't rush this step. Plan out where you want to fit the remaining televisions.

5



Secure the pallet with stretch-wrap. To tightly wrap the pallet, pull the stretchwrap tight as you go around the corners.

6



80-gauge shrink wrap works well for wrapping computer towers. Give the material a push to ensure it is wrapped securely and is stable. Continue wrapping if needed.